

Honeywell Xenon 1902GSR Scanner Setup Sheet

Scan the below barcodes once each in descending order.

Reset to default:

Step 1



DEFAULT.

Activate Defaults



Reset scanner to base before continuing. Wait for several ticks and 1 beep. Continue scanning.

Step 2



SCNLED0.
Lights Off

Step 3



SCNDLY400.
400 milliseconds

Step 4



PREBK2.
Add Prefix

Add ~ Prefix

Step 5



K9K

Step 8



KEK

Step 6



K9K

Step 9



MNUSAV.

Step 7



K7K

Sets Carriage Return

Step 10



SUFGA2

Step 11



VSUFCR.

Sets 1 Character minimum length

Step 12



128MIN.

Step 13



10K

Step 14



K1K

Step 15



MNUSAV.